









Installationsanleitung Beschaltungswerkzeug – Cat.6A (ISO)
Installation guide Termination Tool – Cat.6A (ISO)
Instructions de montage L'outil de câblage – Cat.6A (ISO)




D1 Demontage




021.1576

D2 Demontage




Bei Nichtgebrauch einklappen!
Fold back when not in use!

D3 Demontage




021.1578

D4 Demontage



021.1589

D5 Demontage



021.1590

Headquarters

Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail info@rdm.ch

www.rdm.com

≡ R&M